

## Oyumaru ( Moulding Material) Instruction Sheet

*To soften Oyumaru, place the desired amount into hot water (80DegreesC) for approximately 3 minutes. Press the piece to be duplicated into the softened Oyumaru. Allow the Oyumaru to cool and firm. When the Oyumaru is firm, remove the original piece from the Oyumaru. The mould is now ready for use. Press Art Clay Silver Clay Type into the mould and allow it to harden. Remove carefully from the mould and finish as desired. To reuse Oyumaru, return it to hot water as before and allow it to soften again.*